

Quick use RollerForks®

- Tilt the mast forward so that the taper of the RollerForks can slide across the floor.
- Check whether the slipsheet sticks out on the side where the goods will be lifted.
- Move the RollerForks forward and lower the fork carrier a little so that the taper slides across the floor just in front of the slipsheet.
- Keep driving forward with the mast also tilting forward. The taper needs still to touch the floor until it is under the slipsheet and goods.
- When the taper of the RollerForks is under the slipsheet and goods, you drop the fork carrier downwards immediately so that all rollers touch the floor. This, because of the folding principle in the heel of the RollerForks. Now, the taper doesn't touch the floor anymore.
- Keep on driving forward until the entire load is on the RollerForks. Now tilt the mast backward and lift the RollerForks.

